

Automatic Nursing Machine

Designed to provide a constant, uniform, and easily accessible supply of milk replacer, optimized for 15 calves. The machine automatically mixes up milk replacer with warm water at a desired temperature and concentration. Daily milk qty can be adjusted per calf.

MODEL:

BOVI-15



Adjust feeding qty for each individual calf

Water control knob
- Adjust the water up or down to reach required concentration



RFID Reader

- Radio frequency receiver that can read RFID ear tags wirelessly
- Calves attempting to feed will be identified by the reader via ear tag and only provided qty of milk programmed in the computer
- 25 ear tags included

Specifications

Capacity	optimized for 15 calves
Number of nipples	1 calf nipple
Capacity of hopper	25lbs (9kg)
Capacity of water tank	2gal. (8 l)
Volts	110 volts, 1500 watts
Power requirement	15 amps
Dimension	17 x 19 x 28 inch (43 x 48 x 70 cm)



Milk replacer hopper
- Fits one 25lb bag of milk replacer/formula
- Transfers replacer/formula into the auger and then into the mixing bowl. Two wipers move powder to prevent caking.

Control panel
- Simple ON/OFF operation
- Powder/Rinse
- Thermostat: adjust to desired temperature



Milk mixing bowl

- Mixes hot water and milk replacer on demand

Computer functions

- Calibration of feeding amount and concentration
- Register / remove calf id
- Setting up feeding qty's per calf / all calves
- Checking feeding stats per calf
- Auto wean program for individual calves

Hooks right up to your 3/4" garden hose*



*range of 15 - 40psi