

## DAIRY EQUIPMENT

# Automatic Nursing Machine

Designed to provide a constant, uniform, and easily accessible supply of milk replacer, for up to 28 calves. The machine automatically mixes up milk replacer with warm water at a desired temperature and concentration. Daily milk qty can be adjusted per calf.

MODEL:

## BOVI-28

### Water control knob

- Adjust the water up or down to reach required concentration



### RFID Reader

- Radio frequency receiver that can read RFID ear tags wirelessly
- Calves attempting to feed will be identified by the reader via ear tag and only provided qty of milk programmed in the computer
- 28 ear tags included

### Specifications

Capacity	For up to 28 calves
Number of nipples	1 calf nipple
Capacity of hopper	55lbs (9kg)
Capacity of water tank	4gal. (15 l)
Volts	110 volts, 1500 watts
Power requirement	15 amps
Dimension	18.5x16x36 inch (47 x 41 x 91cm)



# Adjust feeding qty for each individual calf



### Milk replacer hopper

- Fits one 55lb bag of milk replacer/formula
- Transfers replacer/formula into the auger and then into the mixing bowl. Two wipers move powder to prevent caking.

### Control panel

- Simple ON/OFF operation
- Powder/Rinse
- Thermostat: adjust to desired temperature



### Computer functions

- Calibration of feeding amount and concentration
- Register calf id
- Setting up feeding qty's per calf / all calves
- Checking feeding stats per calf
- Auto wean program for individual calf
- Manual mode

### Milk mixing bowl

- Mixes warm water and milk replacer on demand

### Hooks right up to your 3/4" garden hose\*



\*range of 15 - 40psi